

# CONTROLLER SUBMITTAL




## RAC

## YT1F(MOTO)

- This controller suitable for:  
**Free Match Standard Duct**



No.	Name	Fuction
1	ON/OFF (⏻)	Press this button to turn on/off the unit. After that, the sleep function will be canceled but the preset time is still remained.
2	MODE	Auto, Cool, Dry, Fan, Heat modes can be selected circularly by pressing this button. Auto mode is the default after power on. 
3	SLEEP	Sleep On and Sleep Off can be selected by pressing this button. After powered on, the default is Sleep Off.
4	FAN	Auto, Low, Medium, or High fan speed can circularly selected by pressing this button. After powered on, the default is Auto speed. 
5	CLOCK	The clock can be set up by pressing this button, with the ⌚ symbol displayed and blinking. In such a case, pressing + or - within 5 seconds can adjust the value.
6	LIGHT	Light On and Light Off can be set by pressing this button when the unit is at On or Off status. After powered on, the default is Light On.
7	TURBO	In Cool or Heat mode, pressing this button can activate or deactivate this function. When this function is on, its symbol will be displayed.
8	X-FAN	Pressing X -FAN button in COOL or DRY mode, the icon ⚙️ is displayed and the indoor fan will continue operation for 10 minutes in order to dry the indoor unit even though you have turned off the unit.
9	-	The preset temperature can be decreased by pressing this button.
10	+	The preset temperature can be increased by pressing this button.
11	TEMP	It can be decided by pressing this button which temperature will be displayed, indoor set temperature, or indoor ambient temperature.
12	SWING (↔) UP/DOWN	The swing angle which circularly changes as below can be selected by pressing this button: 
13	AIR (🏠)	AIR ON or Air OFF can be selected by pressing this button.
14	TIMER ON	"ON" will be displayed and blink for 5 seconds by pressing this button, and soon adjust the time by pressing + or - within 5 seconds.
15	TIMER OFF	TIMER OFF can be activated by pressing this button, with "OFF" blinking. The method of setting is the same as that for TIMER ON.
16	HEALTH (👤)	This function can be activated or deactivated by pressing this button. After the unit is turned on, the default is HEALTH ON.
17	I FEEL	This function can be activated by pressing this button and canceled by another press.



- When you don't use remote controller for a long time, please take out the batteries.
- If the display on remote controller is fuzzy or there's no display, please replace batteries.

Job Name:

Schedule Reference:

Date:

Specification are subject to change without notice.